





## HOW TO REPAIR YOUR SLOT BOX


USER MANUAL



**1.** Drill the Hole with a 5mm



**2.** Order and use a Self Tapping  
Screw size: M6x13mm  
(SUS303)



**3.** Apply the Screw to the 5mm  
hole by tighten it with a  
cross Screwdriver.